



11. Adjust:

- installed shift rod length
Refer to "ADJUSTING THE SHIFT PEDAL".

EAS00065

MEASURING THE COMPRESSION PRESSURE

The following procedure applies to all of the cylinders.

NOTE: _____
Insufficient compression pressure will result in a loss of performance.

1. Measure:
 - valve clearance
Out of specification → Adjust.
Refer to "ADJUSTING THE VALVE CLEARANCE".
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Remove:
 - rider seat
 - fuel tank
Refer to "SEATS AND SIDE COVERS" and "FUEL TANK".
4. Remove:
 - camshaft sprocket cover
Refer to "ROCKER ARMS, PUSH RODS AND VALVE LIFTERS".
 - decompression solenoid
Refer to "CAMSHAFTS".
5. Install:
 - camshaft sprocket cover
Refer to "ROCKER ARMS, PUSH RODS AND VALVE LIFTERS".
6. Disconnect:
 - spark plug cap
7. Remove:
 - spark plug

CAUTION: _____
Before removing the spark plugs, use compressed air to blow away any dirt accumulated in the spark plug wells to prevent it from falling into the cylinders.

